From time-to-time, a red triangle of doom may begin flashing on the upper right corner of your phone screen.

If you see this, ⚠ Do not panic; your phone will not explode. In most instances, the error appears when your phone briefly loses connection. This indicator can be cleared safely. Follow these steps to remove it:

1.) Press the Home Button 🏠 to access the colored tile menu.

2.) Select 'Settings' using the directional pad on the phone (Image 1).

3.) Navigate to 'Status' either by pressing '4' or using the directional pad (Image 2).

4.) Choose 'Diagnostics' either by pressing '4' or using the directional pad (Image 3).

5.) Open 'Warnings' either by pressing '5' or using the directional pad (Image 4).

6.) All warnings will be displayed in a vertical list. To dump them into the ether, poke the contextual button located under 'Clear.'

Image 1

Image 2

7.) To return to the main menu screen, either press the Home Button twice or wait 30 seconds for the phone to do so automatically.

8.) Celebrate!

Image 3

Image 4